

Door handles installation

Conventional



Handles category

1. Stainless steel handle
2. Zinc base + Alu handle
3. Black handle

● To be combined with Smart door systems

Important: Fitting instruction on reverse

Handles “Conventional”

Handles ready to be installed “Conventional”

Before getting started:

Read these instructions completely before starting:

Handle elements

For the installation you need of course 2 handles, 2 rosettes, a spindle, a hex key and screws.

Tools:

Before you start check if you have the tools you need. These are: a drilling machine and a screwdriver.

Installation of doorframe in simple steps:

1. Now we can install the handle. First, insert the door pin with the exterior handle in the pre-drilled handle hole.
2. Then use the hex key to screw the door pin in the handle.
3. We do the same for the opposite handle.
4. To make sure that the handle is safe installed, we can use the drilling machine to make some small holes in the doorleaf. Use the screwdriver to fasten the handle to the doorleaf with the screws.
5. Then we do the same with the second handle on the other side of the door.
6. Our handles have cover plates. We now take the covers plates and slide them over the handles.
7. Now we take the base plate for the key hole and tighten it with the screws to the doorleaf. And then we use the cap to cover it.
8. Finally we use the same procedure for the base on the other side of the door.
9. The installation of the door handle is now finished and ready to be used.

